Make Smart



Go Together



AIRBEST (CHANGXING)TECHNOLOGY CO.,LTD.

Add: No.809, Changxing Avenue, Changxing Economic Development Zone, Huzhou, Zhejiang, China 313100

Tel: 86-572-6388266 Fax: 86-572-6532123 E-mail: info@airbest.com www.airbest.com www.airbest.cn





AIRBEST Website AIRBEST WeChat ID

AIRBEST



Vacuum Solutions Supplier

AIRBEST



Company Introduction

AIRBEST was established in 2006, engaged in R&D, production and sales of vacuum gripping products (vacuum generators, vacuum suction cups and vacuum grippers, etc).

Products are used in different industries, mainly including intelligent manufacturing, automotive metal stamping, packaging, woodworking, industrial robots, foods, pharmaceuticals, electronics, etc.

We pay attention to the practical application of products, qualityorientation and innovation first. So far we acquired many patents.

AIRBEST constantly serves customers and makes improvements, contributes our professional technology in vacuum gripping field.

Appreciate your attention and support to AIRBEST.









Contents

A	Vacuum Technology
1	Vacuum Technology Introduction
6	Application Symbol
7	Product Characteristics Symbol
8	Thread Instruction
9	Connector Selection
10	PJS Series Universal Insert Fitting
12	PJF Series Locking Fitting
14	PJT Series Thread Adaptor
14	Level Compensator
17	Suction Cup + Fitting
20	Suction Cup + Level Compensator (PSPE)
21	Suction Cup + Level Compensator (PSPF)
22	Suction Cup + Level Compensator
23	Application of Vacuum Technology

B	Vacuum Generators
24	AZK Series
31	AZX Series
36	AZD Series
39	AGS Series
49	AGB Series
51	AGP Series
53	AGX Series
55	AGE Series
58	ABM/ABX Series
64	ABM/ABX Combined type
69	AMC Series
75	AM/AL/AH Series
83	AM/AL Combined type
89	AMD Series
93	AZW Series
96	AZR Series
101	ABT Series
104	ABP Series
106	ABQ Series
108	AEVC Series
111	AZL Series
115	AZH Series
121	AZU Series
124	ACV Series
129	ASBP Series
132	ALS Series
135	ACP Series
138	ACPF Series
141	ACPS Series
143	APB Series

Vacuum Suction Cups 146 SZ Series 154 SP3 Series 168 **SUF Series** 169 SAN Series 170 SAO Series 177 **SOFA Series** 178 STP Series 180 SFT Series 183 SFA Series SBT Series 186 187 SBL Series 190 **SBLP Series** 192 SBS Series 194 SFP Series 197 SBP Series 201 **SXP Series** 205 SGP Series SBOF Series 208 STC Series 211 215 SFF Series 219 **SOB Series** 222 **SOF Series** 226 **SOG Series** 229 SFM Series 233 **SOM Series** 236 SBF Series 239 **SDM Series** 241 SFU Series 245 SFK Series 248 SHT Series 250 SDL Series 251 SFG Series 254 **SFGT Series** 256 SFD Series 258 SB Series SBA Series 263 268 SF Series 274 SU Series 278 SPA Series

333	SBB Series
335	SOP Series
337	SNP Series
Special	Vacuum Grippers
Special	vacuum unppers
339	SLG Series
342	SNC Series
344	SNT Series
346	SLP Series
349	SLB Series
349	
353	SLW Series

SPD Series

SPF Series

SPC Series

SPJ Series

SPU Series

SH Series SHB Series

E	Vacuum Grippers
364	TXN Series
370	TXD Series
373	TXC Series
378	TXM Series
382	TXP Series
384	TXH Series
388	TXL Series

F	Mounting Parts
388	PSPE Series
392	PSPL Series
394	PSPS Series
396	PSPT Series
400	PSPH Series
401	PSPD Series
406	PSPF Series
409	PJS Series
413	PJT Series
415	PJF Series
417	PJB Series
418	PJE Series
419	PJH Series
421	PJP Series
424	PJQ Series
426	PDA Series
428	PDR Series
430	PTS Series
431	PTK Series

G	Vacuum Accessories
436	ZFA Series
435	ZFE Series
437	ZFD Series
438	ZFB Series
440	ZFL Series
441	ZFP Series
443	ZVAB Series
444	ZVAC Series
445	ZVAA Series
446	ZVEA Series
447	ZVR Series
448	ZVRM Series
450	ZVCM Series
451	ZVD Series
452	ZVS Series
454	ZVT Series
455	ZPDT Series
459	ZPDE Series
463	ZPMR Series
464	ZSA Series

287

289

301

307

316

319

326





Vacuum level

The difference between standard atmospheric pressure and absolute pressure.

Pressure unit

Positive pressure conversion table

	Pa(N/m²)	kPa	bar	kg/cm²	torr	psi(ibf/in²)	inHg
1 Pa	1	0.001	0.00001	10.1792×10 ⁻⁶	7.50062×10 ⁻³	0.145038×10 ⁻³	0.3×10 ⁻³
1 kPa	1,000	1	0.01	10.1792×10⁻³	7.50062	0.145038	0.3
1 bar	100,000	100	1	1.01972	750.062	14.5038	30
1 kg/cm²	98,066.5	98.0665	0.980665	1	735.559	14.2233	29.42
1 torr	133.322	0.133322	1.33322×10 ⁻³	1.35951×10 ⁻³	1	19.3368×10⁻³	0.04
1 psi	6,894.76	6.89476	68.9476×10 ⁻³	70.3096×10 ⁻³	51.7149	1	2.07

Negative pressure conversion table

	mbar	kPa	-kPa	%vacuum	torr	-mmHg	-inHg
Atmospheric	1,013	101.3	0	0	760	0	0
pressure	913	91.3	10	9.9	685	75	3
	813	81.3	20	19.7	610	150	6
	713	71.3	30	29.6	535	225	9
	613	61.3	40	39.5	460	300	12
	513	51.3	50	49.3	385	375	15
	413	41.3	60	59.2	310	450	18
	313	31.3	70	69.1	235	525	21
	213	21.3	80	79	160	600	24
	113	11.3	90	89	85	675	27
Absolute vacuum	0	0	101.3	100	0	760	30

Flow

Air volume flows through specified cross section per unit time

Flow conversion table

	m³/s	m³/h	NL/min	NL/s	ft³/min(scfm)
1 m³/s	1	3,600	60,000	1,000	2,118.9
1 m³/h	0.28×10 ⁻³	1	16.6667	0.2778	0.5885
1 NL/min	16.67×10 ⁻⁶	0.06	1	0.0167	0.035
1 NL/s	1×10 ⁻³	3.6	60	1	2.1189
1 ft³/min	0.472×10 ⁻³	1.6992	28.32	0.4720	1

How to produce vacuum


Compressed air flows in high speed, which sucks the air in vacuum chamber, then vacuum chamber has negative pressure



Instructions for suction cups' applications


We separated applications in vacuum applied to sealed and unsealed systems. Sealed systems are all applications where there is no leakage between the suction cup and the substrate

Examples: Handling of glass plates /handling of smooth surface metal plates/ Evacuation of containers / Tests of tightness



Unsealed systems applications are that where there is leaking through the suction cup and the substrate, where the product is porous, or through the edge of the pad in the case of rough substrates. There is the possibility of applications where leakage occurs by both ways

Examples: Handling of cardboard box / Handling of foam/ Handling of rough ceramic floor



Types of suction cups

Flat suction cups

- Small course of work, suitable for fast gripping
- Good for handling flat objects
- Suitable for horizontal or vertical loads and flip over


1.5 Bellows suction cups

- Good for handling objects with uneven surface and curved objects
- Large course of work, compensate for varying workpiece heights
- Suitable for horizontal or vertical loads, slightly flip over

Multiple bellows suction cups

- Large course of work, compensate for varying workpiece heights
- Good for handling objects with uneven surface and curved objects
- Limited load capacity, not suitable for fast gripping and flip over

We recommend the ideal vacuum level for suction cups working is -60kPa~-80kPa, because the energy consumption ratio is greatly reduced when the vacuum level beyond -80kPa



Suction force


Suction force means the maximum weight of the object, which can be gripped in vertical lifting; it is proportional to the pressure difference and effective suction area

Calculation formula of suction force: $F = P \times S$

F = Suction force

P = Vacuum level, the difference between atmospheric pressure and internal pressure of suction cups.

S = Effective suction area



Vacuum Technology Introduction



Lateral force

Lateral force means the maximum weight of the object, which can be gripped in lateral lifting; it is related to suction force of suction cups and friction

Calculation formula of lateral force: $F_1 = P \times S \times \mu$

 μ = Friction coefficient

Friction coefficient " μ " is the ratio of friction and suction force between the suction cups and workpiece, the inner structure of suction cups and surface of workpiece has influence on the friction coefficient. For the same type surface of workpiece, the friction coefficient of suction cups with inner support is larger than the flat suction cups; for the same suction cup, the friction coefficient of workpiece with dry and rough surface is larger than the smooth surface workpiece

Table 1.1 Friction coefficient (reference)


Surface of workpiece	Friction coefficient µ
Wet or oily surface	0.1~0.4
Smooth and flat surface (glass, slate, plastic, metal)	0.5
Rough and flat surface (dry)	1

Safety factor

The suction force or lateral force is theoretical value, many other important factors should be considered in practical application, such as the size and shape of suction cups, smoothness, hardness and shape of workpiece, handling speed, flip over, etc. The safety factor k should be considered when choose the model of suction cups, k≥2

Table 1.2 Safety factor (reference)

Type of workpiece or working type	Safety factor k
Smooth and flat workpiece	2
Smooth and flat workpiece with fast movement or flip over	4
Rough or irregular workpiece	4
Carton packages	4
Softbag packages	6



Selection of diameter of the suction cup

According the formulas, we could calculate the approximate diameter of suction cups

Table1.3 Formulas for diameter for different type of suction cup

D=diameter of suction cup (mm) V=vacuum level (-kPa) k=safety factor (refer to table 1.1) m=weight of workpiece (kg) n=number of suction cups in the application

Type of suction cups	Formula	Type of suction cups	Formula
1.5 bellow type	$D=152\times\sqrt{\frac{m\times k}{V\times n}}$	Multiple bellows	D= $(223.5 \sim 558.5) \times \sqrt{\frac{m \times k}{V \times n}}$
Flat type	$D=139.5\times\sqrt{\frac{m\times k}{V\times n}}$	Theoretical (without deformation)	$D=117\times\sqrt{\frac{m\times k}{V\times n}}$



Example

Sealed system

Determine the type and number of suction cups for handling an aluminum plate, with smooth and flat surface, size 2000x2000mm, weight 260kg. The manipulation will be done through a pulley in the horizontal direction at low speed

The handling surface is nearly smooth and flat Safety factor is 2


To ensure the stability of handling and avoid the deformation and bending of aluminum plate under gravity, we use 8pcs suction cups and calculate the result in case of vacuum level -60kPa

From Table 1.3, we could conclude that:

m=260kg k=2 V=-60kPa n=8
$$D=139.5\times\sqrt{\frac{m\times k}{V\times n}} \implies D=139.5\times\sqrt{\frac{260\times 2}{60\times 8}}=145.19\text{mm}\approx \boxed{150\text{ mm}}$$

According to the result, we could choose AIRBEST flat suction cup SPF150 or SF150

Layout of hoses



Common application (for reference):

- ♦ The diameter mentioned above, for hoses dia.≤16mm means outer diameter; dia. > 16mm, means inner diameter
- ♦ The hoses layout above is for reference only, please consider the actual application



Material characteristic

Material	Short time contact temperature(°C) ≤ 30s	Long time contact temperature(°C) > 30s	Wear resistance	Oil resistance	Weather and ozone	Resistivity
N - NBR	- 20 ~ +110	-10 ~ +80	0	0	0	-
S - Silicone	-40 ~ +250	- 30 ~ +200	×	×	0	_
CN - Conductive NBR	-10 ~ +100	-10 ~ +70	0	0	0	10 ⁵ -10 ⁹
CS - Conductive silicone	-30 ~ +200	- 20 ~ +160	×	×	0	10 ⁵ -10 ⁹
U - Polyurethane	+10 ~ +60	+10 ~ +40	0	0	0	-
F - Fluorine Rubber	-10 ~ +350	-5 ~ +300	0	0	0	-
E - EPDM	- 30 ~ +150	- 20 ~ +120	0	×	0	-
HS - High temp silicone	-20 ~ +300	- 50 ~ + 250	Δ	×	0	-
HD - High temp/mark free material	-10 ~ +180	-5 ~ +160	0	0	0	-
NR - Natural rubber	- 20 ~ +80	- 10 ~ +60	0	×	Δ	-
NF - Neoprene foam rubber	- 20 ~ +80	-10 ~ +60	0	Δ	0	-
OF - Geranium foam rubber	- 20 ~ +80	-10 ~ +60	0	×	×	-

^{⊚:} Excellent ○: Good △: Fair x: Unsuitable

Suction cups storage instruction

Temperature

The suitable temperature for suction cups storage is 15°C~25°C (59°F~77°F)

Humidity

The relative humidity of storage environment should be less than 65% and without condensation, avoid extremely wet or dry storage environment

Please store in dark environment, avoid direct sunlight or strong UV

Radiation

Keep away from ionizing radiation

Ozone

Ozone will cause harm to the products

Deformation

The products should be stored in a loose space to avoid being squeezed

Stock turnover

Follow "First In First Out" for the stocks

Color and hardness of suction cup

Examples

S - Silicone	50	Color is red, calibration hardness is 50°
WS - White silicone	50	Color is white, calibration hardness is 50°
CS - Conductive silicone	• 55	Color is black, there is red dot on surface ,calibration hardness is 55°

Suction cup's color, hardness are shown as above icon for your reference. Besides, slight color difference caused by catalogue printing and difference between calibration hardness of material and actual hardness of suction cup are normal. (Generally within ±5°)

Industry Application Symbols Instruction



UI	Industry	Description	Recommendation		Applicable
			Vacuum generator	Suction cup	Suction cups
	PACKAGING (Carton)	Mainly for handling, logistics, stacking, storage of carton and soon. The features are that the workpiece is easy to deform, porous, medium weight, various sizes, and has high requirement for wrear resistance of the suction cup	Vacuum gripper, multi stage vacuum pump, etc take advantage of flow to compensate leakage loss	NBR, PU, etc. Excellent wear resistance, recommend bellows suction cups	TXC, TXM SB, SPC
	PACKAGING (Plastic Bag)	Mainly for gripping, destacking, handling of plastic bag, purchasing bag, cat food bag and dog food bag. The features are that the workpiece can be both soft and hard and has wrinkles, and has high requirement for deformation and adaptability of suction cup itself	Select vacuum generator accordingto weight and characteristic of workpiece	Silicone, soft and flexible, recommend multiple bellows suction cups	SBL, SBLP STP, SPJ SFA
	GLASS	Mainly for handling, gripping of universal glass, industry glass, float glass and so on. The features are that workpiece is heavy, flat, smooth, hard and it has requirement of powerful lateral gripping force	Select vacuum generator according to weight and characteristic of workpiece	NBR, excellent wear resistance, recommend flat suction cups	SFG, SF
	METAL SHEET (Sheet Metal)	Metal sheet industry, mainly for handling, fixing and processing of metal plate. The features are that the workpiece is easy to deform, with oily surface, curved metal plate, heavy weight and has high requirement for big internal support, anti slip, anti deformatione of suction cup	Select vacuum generator according to weight and characteristic of workpiece	NBR, PU etc. excellent wear resistance ,recommend flat or 1.5 bellows suction cups	SFF, SFM STC, SBF SOF, SOB SDM, SOM
	META SHEET (Thick Metal Plate)	Metal sheet industry, mainly for handling, fixing and processing of metal plate. The features are that the workpiece is, with oily surface, heavy weight and hashigh requirement for large internal support, slip resistance, anti deformation of suction cup	Select vacuum generator according to weight and characteristic of workpiece	NBR,PU ,etc. Excellent wear resistance,recommend flat suction cups	SFF, SFM SDM, SOF SFK
	AUTOMOTIVE	Automotive industry, mainly for glass, curved metal plate, tyreand so on. The features are that metal plate is with uneven andcurved surface, glass is smooth and with heavy weight, and hashigh requirement for slip resistance	Select vacuum generator according to weight and characteristic of workpiece	NBR, PU etc. excellent wear resistance and good oil resistance	SBB, SFG SFF, SFM STC, SBF SOF, SOB
	WOOD	Wood industry, mainly for handling of wood plate, fiberboard, wooden handicraft and so on. The features are uneven surface, porous, heavy weight, good sealness and large internal support for suction cup	Multistage vacuum generator AM/AL,etc. Take advantage of flow to compensate the flow loss between suction cup and workpiece	NBR, excellent wear resistance	SF, SPF SFU, SFD SOM
	FABRIC	Fabric industry, mainly for handling of cloth, gauze and so on. The features are workpiece is easy to deform, porous, light weight, overlap, and has requirement of large vacuum flow for suction cup	Select vacuum generator according to weight and characteristic of workpiece	POM material special gripper, which is with suction cup, recommend flow gripper	SLP, SLB
	COMPOSITE MATERIAL	Mainly for handling leather, fiber plate, the features are that the workpieces are porous, light, and overlapping and hasrequirement of large vacuum flow for suction cup	Select vacuum generator according to weight and characteristic of workpiece	Select suction cup according to actual condition	SLB
	STONE	Stone industry,mainly for handling marble, bricks, and so on.The features are that workpiece is with uneven surface andhas requirement for large deformation of suction cup	Multistage vacuum generator AM/AL, etc. Take advantage of flow to compensate the flow loss between suction cup and workpiece	NF-Neoprene foam rubber OF-Geranium foam rubber large deformation and good tightness, recommend foam rubber suction cup	SOP, SNP
	INJECTION MOLDING	Plastic industry, mainly for handling in latter procedure of plastic injection molding. The features are high temperature resistance, workpiece with curved surface, and has high requirement for high temperature	Select vacuum generator according to weight and characteristics of workpiece	Silicone,HD high temp material, recommend high temp material suction cup	Silicone, HD high temp material, other special custom-made products
	ROBOT	Robot terminal components, supporting robot to grip and handle. The features are that it requires fast response, combined type saving pipes, system with high safety factor.	Select vacuum generator according to weight and characteristics of workpiece	Select suction cup according to workpiece	
	MACHINE	Machine terminal components, supporting intelligent manufactureequipment to grip and handle. The features are that they are small size, light weight, compact and most of them are metal products	Select vacuum generator accordingto weight and characteristics of workpiece	Select suction cup according to workpiece	
	ELECTRONICS (Screen)	Handling of the screen of mobilephone, tablet PC, etc. The featuresare mark free, without deformation, slip resistance, small and light, etc.	Select vacuum generator according to weight and characteristics of workpiece	Flat suction cup,mark free suction cup which is HD material, halogenation, and teflon tape	SNT, SZU SZC, SZB SPC, SLP SP3, etc.
	ELECTRONICS (PCB Board)	Electronics industry, mainly for handling electronic components. The features are that workpiece is with small surface, light weight, without mark, and has high requirement for conductivity of suction cup	Select vacuum generator according to weight and characteristics of workpiece	Materials like NBR, Si or conductive NBR, Conductive Si, etc are soft, wear resistant and or 0.5bellows suction cups	SZU, SZC SZB, SAN SAO, SLB TXC, SP3, etc.
	PHARMACEUTICALS	Pharmaceuticals industry, mainly for handling of medical kits, medical devices, etc. The features are that there is alcohol, chemical reagent on the surface of workpice, and it has high requirement for chemical resistance of suction cup	Select vacuum generator according to working enviroment and characteristic	Special plastic material, corrosion resistance, alcohol resistance, wear resistance, weather resistance	SBOF
	FOOD	Food industry, mainly for handling of bread, chocolate, milk, etc. The features are irregular shape of surface of workpiece, light weight, plastic bag package, and it has high requirement for material of suction cup	Select vacuum generator according to weight and characteristics of workpiece	FDA silicone, soft seal or FDA POM suction cup	SBL, SBLP SNT, SBS
	NEW ENERGY (Photovoltaic)	New energy industry, mainly for handling of solar cell, circuit board. The features are that the workpiece is porous, fragile and require soft contact and large vacuum flow and average air flow	Air flow is well distributed, smoothly gripping	Wafer gripper	SLW
+ -	NEW ENERGY (Li Battery)	New energy li battery industry, mainly for handling of battery pack, battery, The features are corrosion resistant, explosion proof of soft package gripping, safe and reliable	Select vacuum generator according to weight and characteristics of workpiece	Suction cup with corrosion resistant material, such as EPDM , fluorine rubber	SLB,SF SB, etc.

Product Characteristics Symbol Instruction



UI	Characteristic	Description	Applicable suction cups
\$\$\$::::	Porous	Suitable for porous workpiece, main features are that vacuum generator with low vacuum level and large vacuum flow(usually use flow gripper)is through flow to compensate air permeability loss to create vacuum to grip workpiece	SLB, SLP
	Curved surface	Suitable for workpiece with curved surface or certain slope surface. Usually adopt bellows suction cups to compensate the plane.	All bellows suction cups
7	Slip resistance	For workpiece with smooth surface and prevent it from side slip when grip. Generally adopt flat with ribs or flat with pattern suction cup	All flat with ribs suction cups and flat with pattern suction cups
···	Rough surface	Mainly for workpiece with rough surface such as wood plate, stone. In order to prevent air leakage, usually adopt sponge suction cup to compensate the micro space to grip the workpiece	SNP, SOP
G	Heavy load	For gripping workpiece with heavy load, generally adopt heavy load suction cups and mounting parts	Flat suction cup with big diameter PSPH heavy load level compensator.
	Non-rotating	Mainly for workpiece having precise positioning and direction requirement.It needs non-rotating function	Non-rotating level compensator etc.
FDA	FDA	For workpiece requiring safety certificate in food industry of medical industry, usually adopt food grade white silicone of POM scution sups with FDA	WS material suction cup, SNT-P series
	Tube shaped object	Adopt special concave suction cups for tube shaped or stick shaped workpieces	SOG
	Long and narrow object	Adopt oval suction cups speical for long and narrow workpiece	SOB, SOF
	Corrosion resistance	Adopt fluorine rubber or EPDM suction cups for requirements of corrosion resistance, (such as battery liquid, chemical environment)	F/E material suction cups
	Long lifet ime	Adopt suction cups with special material for high weariness occasion which is longer than average life	V/U material suction cups
	Spherical objects	Adopt deep taper suction cup to grip spherical objects	SZD, SBS
	Water resistance Oil resistance	Adopt special suction cups with oil resistant material and design	SFM, SBF, STC, SFF, etc.
田田	Composite product	Composite product integrated with vacuum generator and suction cups, save space,easy to assemble and wide usage	SLB, SLW, SLP, SNT, SLF, etc.
	Anti-deformation	Select different suction cups for different workpieces and conditions to grip workpiece without deformation	SF, SFF, SFT, SFA, etc.
180°C	Temperature resistance up to 180℃	Adopt suction cups with high temperature resistant material for gripping workpiece with high temperature 180℃	HD suction cup, Silicone suction cup
400°C €	Temperature resistance up to 400℃	Gripping workpiece with high temperature 400℃	SHT



M5 M

Thread

M	Male thread
F	Female thread

Types of thread

М	Metric thread
G	British standard pipe thread
Т	NPT thread
N	NPSF thread
R	British conical pipe thread

Example


Types of thread	Size		
М	5	M5:	M5
G	1	G1:	G1/8
Т	4	T4:	NPT1/2
N	8	N8:	NPSF1"
R	12	R12:	R1"1/2

Connection thread instruction

G1M	G1/8 Male thread	G6F	G3/4 Female thread
G2M	G1/4 Male thread	G8F	G1" Female thread
G3M	G3/8 Male thread	G12F	G1"1/2 Female thread
G4F	G1/2 Female thread		

Note: Thread pitch which is not indicated in the catalogue, is considered as national standard coarse thread specification.





PJS



Universal Inserted Fitting for Suction Cup Selection Instruction

Series	Size range					F	itt	ing										Suc	tio	n c	up	coı			on								
	range	ı	45	1	4 8	G	i1	G	i2	G	3	G	4			S	C						SF							S	Т		
		М	F	М	F	М	F	М	F	М	F	М	F	1	2	3	4	5	6	1	2	3	4	5	6	7	1	2	3	4	5	6	7
SB	5	•													•																		
	6		•											•																			
	8	•													•																		
	10-15	•														•																	
	17-20					•	•													•													
	30-40					•	•														•												
	50							•	•		•											•											
SBA	11-78	•				•	•	•	•							•															•		
SBL	15	•														•																	
	20					•	•													•													
	30-40					•	•														•												
	50							•	•													•											
SF	15	•														•																	
	20-30					•	•													•													
	40					•	•														•												
	50							•	•	•	•											•											
	75								•														•										
	110												•											•									
	150												•												•								
	200												•													•							
SU	6-8	•													•																		
	10-15															•																	
	20-30					•	•													•													
	40					•	•														•												
	50							•	•	•	•											•											
SFP	20-30					•	•													•													
	40					•	•														•												
SBP	20					•	•													•													
	30-40					•	•														•												
	50							•	•	•	•											•											
SXP	20-30					•	•													•													
	35-40					•	•														•												
	50						_			•												•											

PJS



Universal Inserted Fitting for Suction Cup Selection Instruction

Series	Size					ı	itt	ing										Suc	ctio	n c	up	100	nne	ecti	on								
	range	N	15	ľ	18	G	1	G	2	G	3	G	4			S	C						SF							S	Т		
		М	F	М	F	М	F	М	F	М	F	М	F	1	2	3	4	5	6	1	2	3	4	5	6	7	1	2	3	4	5	6	7
SGP	25-35					•	•													•													
	45					•	•														•												
	55							•	•	•	•											•											
SZD	10-16		•														•																
	25		•															•															
	40				•														•														
SZC	10-16		•														•																
	20-32		•															•															
	40-50				•														•														
SZU	2-8		•											•																			
	10-16		•														•																
	20-32		•															•															
	40-50				•														•														
SZB	6-8		•											•																			
	10-16		•														•																
	20-32		•															•															
	40-50				•														•														
SPA	10-20A	•																										•					
	15-20B	•																										•					
	15X	•																										•					
	30B	•																											•				
	25-50A			•																													•
SPC	5-7	•																										•					
	30-60			•																											(
	90					•																											
SPF	2-3.5	•																									•						_
	5-15	•																										•					
	20	•																											•				
	25-40	•																												•			
	50			•																												•	
SPJ	4	•																									•						
	6-15	•																										•					
	20-25	•																											•				
	30-40	•																												•			
	50			•																													

Example: SB5-M5M,fitting for suction cup: PJS-M5M-SC2

 $[\]diamond$ Note: For detailed size of fitting for suction cup, please refer to related content of PJS series from page 409

 $[\]diamond$ Note: For sizes of SC, SF, ST type fitting, please refer to page 410-412

PJF

AIRBEST

Mounting Parts for Universal Suction Cup -Locking Fitting Selection Instruction

Series	Size		!	Suction cup connect	ion	
	range	M5F	M8F	G1F	G2F	G3F
SB	5-15	•				
	17-40			•		
	50				•	•
	75				•	
SBA	11-25	•				
	33-78				•	
SBF	All sizes				•	•
SBOF	All sizes				•	
SFT	15-24	•		•		
	30-40				•	
SBL	15	•				
	20-40			•		
	50				•	•
SBLP	30				•	
	40					•
SF	15	•				
	20-40			•		
	50				•	•
SU	2-8	•				
	20-40			•		
	50				•	•
SUF	All sizes	•				
STC	All sizes				•	
SFF	All sizes				•	
SFM	50-120				•	
SOB	All sizes				•	
SOF	All sizes				•	
SOG	15×40	•				
	35×100				•	
SFP	All sizes			•		
SBP	10-15	•				
-	20-40			•		
	50				•	•
	70					•
SXP	20-40			•		
	50				•	•
	70				_	•

PJF



Mounting Parts for Universal Suction Cup -Locking Fitting Selection Instruction

Series	Size		S	uction cup connec	ction	
	range	M5F	M8F	G1F	G2F	G3F
SGP	25-45			•		
	55				•	•
SAN	All sizes	•				
SAO	All sizes					
SPA	10-20	•				
	30B	•				
	25-50		•			
SPC	5-7	•				
	10-20	•				
	30-60					
	90					
SPF	2-3.5					
	5-8	•				
	10-15	•				
	20	•				
	25-40	•				
	50					
	60-95					
	120-300					
SPJ	4					
	6-8	•				
	10-15	•				
	20-25	•				
	30-40	•				
	50					
	60-80					

PJT





Thread(1)	Thread(2)											
	M5F	М5М	M8F	M8M	G1F	G1M	G2F	G2M	G3F	G3M	G4F	G4M
M5F	•											
M5M		•	•	•								
M8F		•	•									
M8M				•	•	•						
G1F				•	•							
G1M						•	•	•				
G2F						•	•					
G2M								•	•	•		
G3F								•	•			
G3M										•	•	•


Example: PJT-M5M-M8F

♦ Note: For detailed sizes of adapter, please refer to PJT series on page 413-414

Level compensator selection instruction

Series	Applicable industry	Description
PSPE	Electronics industry for light and small load	Small and light level compensator, port specifications are M5 male thread and SC type
PSPT	All industries	Conventional level compensator Port specification is M8, G1/8, G1/4, G3/8 male thread and G1/8, G1/4 female thread
PSPH	Metal sheet,automotive, machinery,etc. for heavy load	Heavy-duty level compensator, connection thread on suction cup side is G3/8, G1/2 male thread
PSPF	All industries,mainly used with suction cup SPA series, SPJ series, SPF series	Compact external level compensator, port specification is M5, M8 female thread, M10 male thread
PSPD	Metal sheet, automotive, machinery, glass, packaging, etc. For heavy load	Double spring heavy-duty level compensator, can balance the deformation of the workpiece and the mounting plate of the level compensator
PSPL	For light or small size load,such as electronics industry	Retraction type level compensator, thread of connection port is M5 female thread





Level Compensator Selection Instruction




Series	Vacuum		Buffer stroke (mm)										Vacuum port+rotary type					
	port	connection	6	10	15	20	25	30	40	50	60	75	90	110	Nil Vertical rotating	R Vertical non-rotating	L Lateral rotating	B Lateral non-rotating
PSPE	M5M	M8	•	•	•		•										•	•
	M5M	M10		•		•		•	•	•					•	•	•	•
	M5F	M10		•		•		•	•	•					•			
	M8M M8F	M14		•		•		•		•					•			
PSPT	M8M M8F	M14		•		•		•		•					•			
	G1/8M	M16		•		•		•		•					•		•	
	G1/8F	M16		•		•		•		•					•			
	G1/4M	M18		•		•		•		•					•	•		
											•	•	•	•	•			
	G1/4F	M18		•		•		•		•					•			
	G3/8M	M18		•		•		•		•					•	•		
											•	•	•	•	•			
PSPH	G3/8M	M30					•			•		•	•		•			
	G1/2M	M30					•			•		•	•		•			
PSPD	G1/4M	M20					•			•					•	•		
	G3/8M	M30					•			•			•		•	•		
	G1/2M	M30					•			•			•		•	•		
PSPL	M5F	M10		•	•	•									•			
Series	Vacuum port	Mounting connection					But	ffer s	troke						Vacuum port+rotary type			
				4		6		10		15			30)	Nil Vertical rotating		L Lateral rotating	
PSPF	M5F	M11		•				•								•		•
		M14				•					•					•		•
	M8F	M14				•					•					•		•
	M10M	M16						•					•					•

 $[\]diamondsuit$ Note: " \bullet " $\,$ - standard type, contact with sales if need customized one

Selection Instruction for Suction Cup and Fitting for Suction Cup AIRBEST

Suction cup(without fitting)+PJS series fitting for suction cup




vacuum pad connection port specifications are matching

Suction cup(without fitting)











Suction cup + PJS series fitting for susction cup






Note: 1. For description of shape of fitting for suction cup which is non-integrated vulcanized with fitting (it means that suction cup can be changed separately), please refer to PJS series fitting for suction cup on page 10-11 or parts selection of each series of suction cups. For actual dimensions of fitting, please refer to PJS series 409-412

2. All of fitting for non-integrated vulcanized suction cup can be found in instruction of each series, which is easy for customers to select model

Suction cup(with fitting)+PJT adapter



Note:1. The above example is fitting for suction cup changing from M5M to M5F

2. Please refer to convertible specifications of PJT adapter on page 14, and real dimensions on page 413-414

Suction cup(with fitting)+PJF locking fitting









PJF Locking fitting






The specifications of fitting for suction cup matches

Suction cup(with fitting)+PJF Locking fitting






Note: 1. The above example is suction cup SPC10N with locking fitting PJF-LB6-M4F-M5F


2. Please refer to detailed specifications of PJF adapter on page 415-416

Selection Instruction for Suction Cup+Level compensator (PSPE) AIRBEST





Suction cup(with fitting)+ Level compensator



Note: 1. The above example is suction cup SPC20N-M5M with level compensator PSPF-E6LB6M5F-M14 2. Please refer to PSPF level compensator on page 406-408

Selection Instruction for Suction Cup +Level Compensator



Recommend applicable level compensators according to suction cups

Series	Size range		nend leve T standa	el compen rd)	sator		Series	Size range	Recommend level compensator (AIRBEST standard)					
		PSPE	PSPT	PSPH	PSPF	PSPD			PSPE	PSPT	PSPH	PSP		
SB	5-15	•					SBP	10-15	•					
	17-75		•					20-70		•				
	110-150			•			SXP	All sizes		•				
SBA	11-25	•					SGP	All sizes		•				
	33-78		•				SDL	All sizes		•				
SBB	All sizes			•		•	SZD	10-25	•					
SBF	All sizes		•					40	•	•				
SBOF	All sizes		•				SH	All sizes		•				
SFT	15-24	•	•				SHB	All sizes		•				
	30-40		•				SZC	10-32	•					
SFA	All sizes	•						40-50	•	•				
STP	All sizes		•				SZU	2-32	•	-				
SBL	15	•						40-50	•	•				
	20-50		•				SZB	6-32	•					
SBLP	30		•					40-50	•	•				
	40-50 *						SAN	All sizes	•					
SF	15	•					SAO	All sizes	•					
	20-75		•				SPA	All sizes				•		
	110-200			•		•	SPC	5-60				•		
	300*							90		•				
SU	2-8	•					SPF	2-95				•		
	20-80		•					120-200*						
SUF	All sizes	•					SPJ	4-50				•		
SFG	All sizes			•		•	-	60-80		•				
SFU	All sizes			•		•	SPU	10-50				•		
STC	All sizes		•					60-100		•				
SFF	All sizes		•				SNP	50-75		•				
SFM	All sizes		•				2	68						
SDM	All sizes		•					140						
SHT	All sizes		•				SOP	40-64						
SOB	All sizes		•				301	92		•	•			
SOF	All sizes		•					127-220						
sog	15×40	•						127-220				-		
	35×100		•											
SFP	All sizes		•											

Note:1. "●" means that selected suction cup directly matches the recommended level compensator 2. "*" means that there is no level compensator directly for this item

Application Instructions of Vacuum Technology



Working Environment

Warning

- 1. Protection measures must be provided to ensure safety, if there is risk of falling
- 2. Because the connector of the vacuum device is not explosion-proof, the pressure in vacuum pipe which is 0.1MPa or more for a long time is not safe, please note
- 3. When there are two pieces or more suction cups connected to one vacuum generator, the workpiece may fall off if one of the suction cups failure
- 4. Do not use the products in the environment with corrosive gas, flammable gas, explosive gas, chemicals, seawater or steam, which are not allowed enter into the vacuum system
- 5. Don't block the ports of vacuum generators or increase the exhaust resistance, will otherwise it cause flow loss or vacuum reduction
- 6. Protective cover should be added when the equipment is exposed in sunlight directly
- 7. Avoid using the equipment in environment of excessive vibration, which may cause failure

Design/Setting

Note

- 1. Please pay attention to the vacuum level drop, it may be caused by the unstable air supply or power supply failure, and the workpiece may fall. Protective measures must be made
- 2. Check the mark of each port on vacuum generator, wrong connection to the vacuum system will damage the equipments
- 3. The supplied air to vacuum generator should be clean, and lubricant should not be used in the supplied air. Impurities or oil in compressed air will cause failure and reduce the performance
- 4. If there is leakage from workpiece or pipes, the vacuum flow will not be enough to hold the workpiece. If the connection pipe is too long or thick, the action time will be longer as the volume of pipe is increased
- 5. The effective sectional area of pipe for vacuum port should be selected according to the maximum vacuum flow of the vacuum generator. The effective sectional area of pipe for air supply port should be selected according to the maximum air consumption of the vacuum generator

Maintenance

Warning

- 1. Elements of silencer and filter elements should be maintained and examined regularly. Block in elements will reduce the performance or cause products damage
- 2. Need to study the components of vacuum generator before replacement.
- 3. Do not wash or spray equipment with water or solvents
- 4. In vacuum system, do not use lubricator in the front pipe of vacuum generator, dirties will be blocked in the nozzle and affect the performance of vacuum generator
- 5. Do not use PTFE tape for connection use (especially the fittings), this tape would fall off easily and block the pipe, affecting the performance of vacum generator

Installation

Warning

- 1. Don't block the ports of vacuum generators or increase the exhaust resistance, otherwise is will cause flow loss or vacuum reduction
- 2. Do not remove the shell, the shell will be damaged or leaking if it's forced to shake or rotate
- 3. Do not use the equipment in the flammable or explosive environment, which may cause fire or explosion